



Large-format microshutter arrays for JWST NIRSpec

H. Moseley for the NIRSpec Microshutter Team

JWST NIRSpec




- **ESA has scientific and managerial responsibility for delivery of Near Infrared Spectrometer (NIRSpec)**
- **Programmable multi-object spectrometer: 342 x730 pixels - our team is developing microshutter array - 2D programmable mask, NASA contribution to the instrument**
- **0.6 - 5.5 um wavelength range**
- **Field of view 3.5'x3.5'**
- **Resolving power 100 - 1000**

Drilled Plate MOS



Hubble UDF image



JWST key science: epoch of initial galaxy formation -- faint galaxies.

Typical half light diameters are $0.2''$ (HDF-S STIS image).

Sky is empty! At lowest isophote, 33.2 AB per $0.1''^2$ covers only 5% of sky.


Typical: > 200 galaxies at $R \sim 1000$ in NIRSpect FOV

Programmable aperture mask requirements




- **Random Access Addressing**
 - Must allow the opening of any shutter distribution
 - > 200 objects simultaneously targeted
- **Must cover NIRSpec FOV (9 sq. arcmin)**
- **Individual slit size; ~ 0.2'' x 0.4''**
- **Contrast**
 - Must have open to closed transmission ratio of >2000 (10,000 goal)
- **Lifetime**
 - Must operate for ~ 10^5 cycles with minimal failures
- **Must operate in the JWST environment**
 - T ~ 35 K
 - Must meet power dissipation requirements (50 mW average at 35 K)
 - Must fit envelope in NIRSpec instrument
 - Must meet mass requirements
 - Radiation - 48 kRad life dose


NIRSpec instrument layout



Initial concept of the Microshutter Design





Cross Section of Unit Cell



Actuation and addressing concept




- Large displacement actuation done magnetically
 - Requires magnet scan mechanism
- Electrostatic latching and addressing
 - Crosspoint addressing requires no on-chip active electronics
- Actuation cycle: < 1 min
- Latch voltages: up to +/- 80V (+/-22V typical)




(a) All Closed

(b) Actuate and Latch All




(c) Release Selected Row 1



(d) Hold Configuration


Microshutter back side - wall electrodes





ESTC06 June 27, 2006

G O D D A R D S P A C E F L I G H T C E N T E R

Magnetic Stripes and Light Shields




Front and back electrodes





128x64 shutter array





Bare 128 x 64 array



128 x 64 array bonded to Si substrate and mounted on PC board




128x64 shutters actuated



ESTC06 June 27, 2006

G O D D A R D S P A C E F L I G H T C E N T E R

PC board mounted large format array 171x365



First fabricated - Aug. 2005

ESTC06 June 27, 2006


G O D D A R D S P A C E F L I G H T C E N T E R

Full array addressing




171 shutters


365 shutters



Microshutter
orientation





Microshutter addressing: the movie




ESTC06 June 27, 2006

G O D D A R D S P A C E F L I G H T C E N T E R

Functional test facility



Functional and optical performance





Array of source masks:
from single pinhole to
17x17 pinholes (50um -
1mm)
Wavelengths: 0.6 um -
5um
Capability to measure
contrast 10^4 and higher


Contrast ratio requirement:
goal: $> 10^4$

Measured:
Visible: 2000 - 55000
Infrared: > 2000

Functional test facility



Functional and optical performance




Array of source masks:
from single pinhole to
17x17 pinholes (50um -
1mm)
Wavelengths: 0.6 um -
5um
Capability to measure
contrast 10^4 and higher

Contrast ratio requirement:
goal: $> 10^4$

Measured:
Visible: 2000 - 55000
Infrared: > 2000


Life test facility



Accelerated lifetest.

- 4Hz actuation
- full 2D addressing
- both room T and cryo
- PC board and quad
- high res imaging, full array imaging

Lifetest cryostat




ESTC06 June 27, 2006


G O D D A R D S P A C E F L I G H T C E N T E R



Microshutter array layout in NIRSpec




Micro-Shutter System (MSS) Flight Configuration




Microshutter development progress



171x365 array - 2005




**First flight design
quad - 2006**



128x64 array - 2004

32x32 array - 2002

Single shutter - 1999



MSS - 2008



Summary

- Pilot 128x64 array development completed
- High contrast ratio
- Cosmetically clean on all closed/open/addressed
- A number of flight format 171x365 has been fabricated and tested on PC board
- A first light design 171x365 QUAD array has been tested functionally (environmental testing: vibration, radiation, acoustic)
- TRL-6 Aug. 2006
- Engineering Unit 2007
- Delivery to ESA 2008