




Modeling the Performance of Optical Refrigerators

**G. L. Mills and A. J. Mord
Ball Aerospace & Technologies Corp.
Boulder, CO USA**

**Earth Science Technology Conference
June 28-30, 2005
Adelphi, MD**




The Photon-Phonon Refrigeration Cycle



Energy levels of Yb^{3+} ion
in ZBLAN glass host




Optical Cooling Process: Optical Pump Photons Remove Heat Phonons




- Pump photon absorbed by Yb dopant atom
- Photon re-emitted slightly bluer (higher energy)
- Energy difference comes from thermal vibrations (phonons) of host material

- High-reflectivity mirrors provide long path length for pump beam
- Fluorescence escapes from uncoated sides of cooling element






Simplified Design of Compact IR Detector / Cryocooler Package Capable of Lifting 400 mW at 80 Kelvin





Fluorescent element is Yb doped Zirconium Fluoride glass (ZBLAN)





Comparison to other Cryocooler Technologies is Favorable in Many Areas

- **Vibration**
 - Optical cryocooler is solid state; zero vibration is an obvious advantage
- **Electromagnetic and magnetic noise**
 - Optical cold head uses only photons, no electrons: no noise
 - Laser can be remotely located to minimize noise; split Stirling machines can have remotely located compressors, but with significant drawbacks
- **Reliability and lifetime**
 - No moving parts, laser is the life limiting component
 - Solid state lasers are made up of many diodes whose output is joined together by optical “Y” junctions
 - Laser diode modules have lifetimes of several years with a Gaussian lifetime distribution
 - Redundancy is inherent; more can be added with no impact on thermal performance



Comparison to other Cryocooler Technologies is Favorable in Many Areas (continued)

- **Extreme environments**
 - The glass cooling element is separated from the heat sink by a gap; it is inherently protected from physical stress
 - Glass cooling element has a compact form factor that withstand high accelerations
 - High temperature environment: fluorescent cooling process is not directly affected by temperature of the heat sink.
- **Miniaturization**
 - Complete cryocooler with less than 1 cm³ volume appears possible.
 - Sub-millimeter diode lasers already exist
- **Cost**
 - Technology used permits low-cost manufacture
 - No high-precision mechanical assemblies
 - Material and process issues are all ones that have been worked out for high-volume industries




Technology Readiness Assessment Shows History, Current Status and Development Direction of Technology

- **TRL 1: *Basic Principles Observed and Reported***
 - LANL in 1995: Less than 1 °C cooling observed in isolated glass
- **TRL 2: *Technology Concept Formulated***
 - LANL and Ball 1996 to 1998: Achieve 50 °C cooling in isolated glass
 - Ball in 1999: System design study based on LANL data concludes it is a feasible technology for cooling small devices
- **TRL 3: *Technology Critical Function & Proof of Concept* ← **Today****
 - Ball-NASA ATIP program discovered and solved mirror leakage problem; allowing a load to be cooled
 - Load cooled 15.6 °C with 145 watt/watt specific power
 - Photon recycling with photocells may increase overall efficiency 5 X
 - LANL has cooled an isolated fluorescent element to 208 K
- **TRL 4: *Concept-Enabling Level of Performance***
 - Will require cooling a load 150 °C (to 150 K) and < 35 watt/watt to be competitive with multi-stage thermoelectrics
- **TRL 5: *Breadboard in Relevant Environment***
 - Should come quickly after TRL 4 achieved



Optical Refrigerator Model


- Tracing the life history of the incoming pump photons
- Tracing the life history of the outgoing fluorescent photons
- Evaluating the internal and external heat transfer





Tracing the life history of the incoming pump photons


- 1) Absorption by Yb, which includes the reduction by saturation at high power densities.,
- 2) Absorption by anything else, including unknown contaminants that can only be described empirically,
- 3) Leakage out through mirrors,
- 4) Leakage out through feed hole, and
- 5) Leakage out through imperfect mirror edges






Tracing the life history of the outgoing fluorescent photons, the possible fates

- 1) Escape through the end mirrors (as much as 27%)
- 2) Escape through the sides
- 3) Re-absorption by Yb (recycling)
- 4) Absorption by anything else, which is assumed to cause heating






Photon Model Results for 2% Yb:ZBLAN Fluorescent Element, 15 x 7 x 7 mm



- Efficiency drops with T due to Boltzmann distribution
- Optimum λ for at given T because of $\Delta\lambda$ vs. absorption length
- At lower T , power saturation effects become significant




Performance of Refrigerator with 2% Yb:ZBLAN Fluorescent Element, 15 x 7 x 7 mm



- Heat leak calculated from thermal model and is independent of lift
- Available heat lift is difference between lift and leak



Optical Cryocooling has the Lowest Spacecraft System Mass in this Region






The Challenge of Cryogenics on a Small Scale

- Workshop sponsored by Dr. Clark Nguyen of DARPA on micro cryocooling held in July 2003 explored possibility of cryocoolers with a total volume of 2 cm³ and less than 100 mW power draw.
- “The Navy’s use of cryogenic devices would increase if they had less impact, such as being small enough to fit on VMX circuit card like any other component.” - Navy consultant in at M-CALC IV cryocooler conference, Nov. 2003
- January 2005: DARPA releases Broad Area Announcement (BAA) 05-15, “Micro Cryogenic Coolers” which solicits development of small cryogenic systems based on:
 - MEMS fabrication
 - Targeted cooling
 - Miniaturization of cooled device and cryocooler
- BAA 05-15 goal: cooled device and cryocooler with a ...
 - Volume of less than 4 cubic centimeters
 - Power draw of less than 100 mW




Our Answer: An Entire Cryogenic System with a Volume of 3.0 Cubic Centimeters

- **Artist's rendering of a micro cryostat containing:**
 - A transition edge bolometer operating at 90 K
 - Yb:ZBLAN fluorescent element
 - A diode laser
 - Vacuum insulation
- **Terahertz antenna mounted on outside.**
- **Applications include:**
 - Non-destructive imaging and inspection through normally opaque materials
 - Detection and identification of chemical compounds
- **Micro cryostat could accommodate other small cryogenic devices such as superconducting filters or amplifiers**
- **Size, volume, power < 10 X less than current S. O. A.**






Heat Lift of 2% Yb: ZBLAN Fluorescent Element Pumped with 300 mW and 1035 nm



- Increasing length increases efficiency and heat lift; pass loss reduced
- Increasing cross section decreases saturation but also increases reabsorption and “reddening” of the fluorescence



Radiative heat load on fluorescent element results in optimum configuration for 300 mW input



- Total heat load includes 5 mW from application device and interface device at 90 Kelvin operating temperature
- Optimum occurs at 10 mm length and 3 to 4 mm width



Conclusions

- **We have developed a comprehensive model of the photon and thermal process of optical refrigerators.**
- **Model is very useful in guiding design**
 - Optimizing wavelength
 - Optimizing fluorescent element geometry
 - Yb:ZBLAN fluorescent elements are not practical at lengths less than 5 mm
 - Optical refrigeration using Yb:ZBLAN can meet DARPA volume goal
- **Possible follow-on work**
 - Extend model to cooling materials other than Yb:ZBLAN
 - Model crystalline materials with non-isotropic absorption and emission